



XR1.2 FRONT UPDATE KIT

LF

- .400" Bump Steer Spacer
- Slot on Rack – 9/16" up
- Tie rod all the way back on spindle arm
- Run 2" of Toe Out
- Caster 4*
- Camber 6*

RF

- .200" Bump Steer Spacer
- RF Upper control arm slugs (Black slug in frame) Flip upside down (hole goes down)
- Slot on Rack 1-1/16" Up
- Tie Rod all the way back on spindle arm
- RF Tie Rod Preset to 19-7/8"
- Caster 6*
- Camber 5* – 5.5* max
- We recommend grinding your ball joint to avoid contact with the shock body

Rack Spacer Goes on with the high point to the RF.

- Use the longer rack bolt provided for the RF where the spacer is the thickest.

RF Shock & Spring Options

8" 175/8" 500 STACK

15.250 1100-1130
14.250 1500-1530
13.250 2450-2500

14" 175 W/ BLUE PENSKE

14.250 1500-1550
13.250 2200-2300

14" 200 W/ BLUE PENSKE

14.250 1500-1550
13.250 2200-2300