



XR1.2 REAR UPDATE KIT

RR 4 Link plates moved in – Silver ½” Spacer goes in between the frame tab and the black aluminum 4 link plate to move the entire plate assembly to the left. (These spacers will be tough to get in due to the close tolerance to the frame bar)

- RR Top rod will go in the second hole from the top
- RR Bottom rod will go in the top hole

- LR Top rod will go in the bottom hole
- LR Bottom rod will go in the bottom hole

These 4 link rod locations will now serve as your standard starting point.

- Make your LR Top Rod 17-3/4” c-c
- Raise your J-Bar on the Pinion to the Center