



Rocket XR1 LRA Clamp Shock

Fox or Integra Shock

Instructions for Mounting

LR Hanging on droop chain, RR setup rod set to 18.5" c-c

Install Shock on STD aluminum LRF Shock mount in the outside hole (3rd Hole)

Clamp on axle tube - 1.5" off the drop limiter then rotate mount until the c-c of the shock is 20" (ideally do this with a setup rod) The angled shock mount should angle inwards like the angle of the shock.

About the LRA Clamp Shock

This shock is ideal for big or fast / momentum racetracks. This will promote LR drive and straight line traction. With this setup you will feel freer on entry so you may need to adjust accordingly to keep the car straight to avoid breaking traction.

Adjusting the LRA Shock

To start the night you will start the shock on the standard settings labeled on the shock (can be different based on build) Later on when the track slickens up you will need to take compression out with the shaft adjuster. If you have a non adjustable shock you do not have to worry about adjusting it - The adjustments on the adjustable shock are for more fine tuning.

